

ENGLISH

Quick start guide 3

Frequently Asked Questions (FAQ) 3

Tech Specs 3

 AUDIO 3

 ACTIVE NOISE CANCELLING (ANC) 3

 CONNECTIVITY 3

 HANDSFREE MICROPHONE 3


 EARPIECE BATTERY 3

 CHARGING CASE BATTERY 3

Care and maintenance 4

Warranty 4

ENERGY♥SYSTEM



Thank you for trusting us and purchasing your new Energy earphones. We hope you enjoy it.

Quick start guide

Consult the quick guide by clicking [here](#).

Frequently Asked Questions (FAQ)

- **How do I reset the headphones?** Disconnect the earphones from any Bluetooth sound source, put them in your ears and press 10 times quickly the touch control of both earphones simultaneously, you will hear a 'beep' sound and they will turn off automatically. Put them in the charging case and when you take them out again you can connect them again via Bluetooth.

Tech Specs

AUDIO

- Frequency response: 20 Hz ~ 20 kHz
- Driver diameter: 10 mm
- Maximum power: 5 mW
- Design: In-ear
- Type: dynamic
- Impedance: 32 Ohm
- THD: < 1%

ACTIVE NOISE CANCELLING (ANC)

- Up to -30 dB reduction between 20 and 1000 Hz

CONNECTIVITY

- Bluetooth version 5.4, class II
- Operating frequency: 2.4 GHz
- Maximum signal strength: < 20.00 dBm
- Supported Bluetooth profiles: HSP / HFP / A2DP / AVRCP
- Supported Bluetooth codecs: SBC / AAC
- Up to 20 metres range
- Hands-free function
- Google/Siri compatible voice assistant

HANDSFREE MICROPHONE

- Type: Built-in
- Sensitivity: -38 dB ± 3 dB
- Frequency range: 100 Hz ~ 10 kHz

EARPIECE BATTERY

- Capacity: 40 mAh / 3.7 V
- Type: Lithium polymer
- Battery life at medium volume: 5 hours
- Charging time: 1 hour

CHARGING CASE BATTERY

- Capacity: 500 mAh / 3.7 V
- Type: Lithium polymer
- Extra autonomy: 20 hours
- Charging time: 2 hours
- Charging system: USB Type C

*This figure is approximate. Battery life depends on volume selected and type of music played.

Care and maintenance

- Do not expose the device to shock, dust, humidity or high temperatures.
- Do not use corrosive or abrasive cleaning agents.
- Do not disassemble. Any repair must be done exclusively by qualified Energy Sistem Technology, S.A. personnel.
- Be sure to keep your product turned off when not in use and do not leave it for a long period of time with the battery completely discharged.

Warranty

You can check the warranty conditions [here](#).