The flip phone of your dreams

Give your smartphone a vacay


Nothing beats spending real time together. That's what the HMD Barbie Phone is all about! No distracting apps here. The real magic happens with our friends and family, not on our screens.

The Barbie look is calling

This flip phone is chic, sleek and pink – and that's just on the outside. Open it up and everything on the screen feels like it's straight out of the Barbie DreamHouse™ – with a few hidden surprises for you to find.

Live your dream life

This may be the HMD Barbie Phone, but this is about your style, too! It comes with Barbie covers, each with a different design. Switch them up as often as you like, then make them your own with the included stickers and crystals. It even has a beaded lanyard with iconic Barbie charms for added style. We all have a unique sparkle to show the world. So, show it!







Networks: GSM/GPRS 900/1800, WCDMA, LTE Cat1

OS: S30+

Variant: Dual SIM/Single SIM

CPU: T107

Storage: 128MB¹+64MB (ROM/RAM), Micro SD

support up to 32 GB

Display: 2.8" internal screen & 1.77" external screen

Connectivity / Bluetooth® (5.0), USB Type-CTM, and 3.5mm

sensors: AV jack

Battery: 1450mAh² battery.

Audio: MP3 Player³, FM radio (Wired/Wireless)

Dimensions: 108.4*55.1*18.9 123.5g

Camera VGA camera with torch as flash

SIM card type: 4FF + 4FF

Battery times: Talk time up to 9 hours (in the lab

environment)

BARBIE™ and associated trademarks and trade dress are owned by, and used under license from, Mattel. ©2024 Mattel.

TM and © 2024 HMD Global. All rights reserved. Variations on offering may apply. Check local availability. All specifications, features and other product information provided are subject to change without notice. All images are for illustrative purposes only. Contains small parts. ¹Preinstalled system software and apps use a significant part of memory space. ²Battery has limited recharge cycles and battery capacity reduces over time. Eventually the battery may need to be replaced. ³MicroSD card required, sold separately.

The flip phone of your dreams

Give your smartphone a vacay

Nothing beats spending real time together. That's what the HMD Barbie Phone is all about! No distracting apps here. The real magic happens with our friends and family, not on our screens.

The Barbie look is calling

This flip phone is chic, sleek and pink – and that's just on the outside. Open it up and everything on the screen feels like it's straight out of the Barbie DreamHouse™ – with a few hidden surprises for you to find.

Live your dream life

This may be the HMD Barbie Phone, but this is about your style, too! It comes with Barbie covers, each with a different design. Switch them up as often as you like, then make them your own with the included stickers and crystals. It even has a beaded lanyard with iconic Barbie charms for added style. We all have a unique sparkle to show the world. So, show it!



Product specifications:



Networks: GSM/GPRS 900/1800, WCDMA, LTE Cat1

OS: S30+

Variant: Dual SIM/Single SIM

CPU: T107

Storage: 128MB¹+64MB (ROM/RAM), Micro SD

support up to 32 GB

Display: 2.8" internal screen & 1.77" external screen

Connectivity / Bluetooth® (5.0), USB Type-CTM, and 3.5mm

sensors: AV jack

Battery: 1450mAh² battery.

Audio: MP3 Player³, FM radio (Wired/Wireless)

Dimensions: 108.4*55.1*18.9 123.5g

Camera VGA camera with torch as flash

SIM card type: 4FF + 4FF

Battery times: Talk time up to 9 hours (in the lab

environment)

BARBIE™ and associated trademarks and trade dress are owned by, and used under license from, Mattel. ©2024 Mattel.

TM and © 2024 HMD Global. All rights reserved. Variations on offering may apply. Check local availability. All specifications, features and other product information provided are subject to change without notice. All images are for illustrative purposes only. Contains small parts. ¹Preinstalled system software and apps use a significant part of memory space. ²Battery has limited recharge cycles and battery capacity reduces over time. Eventually the battery may need to be replaced. ³MicroSD card required, sold separately.

The flip phone of your dreams

Give your smartphone a vacay


Nothing beats spending real time together. That's what the HMD Barbie Phone is all about! No distracting apps here. The real magic happens with our friends and family, not on our screens.

The Barbie look is calling

This flip phone is chic, sleek and pink – and that's just on the outside. Open it up and everything on the screen feels like it's straight out of the Barbie DreamHouse™ – with a few hidden surprises for you to find.

Live your dream life

This may be the HMD Barbie Phone, but this is about your style, too! It comes with Barbie covers, each with a different design. Switch them up as often as you like, then make them your own with the included stickers and crystals. It even has a beaded lanyard with iconic Barbie charms for added style. We all have a unique sparkle to show the world. So, show it!





Networks: GSM/GPRS 900/1800, WCDMA, LTE Cat1

OS: S30+

Variant: Dual SIM/Single SIM

CPU: T107

Storage: 128MB¹+64MB (ROM/RAM), Micro SD

support up to 32 GB

Display: 2.8" internal screen & 1.77" external screen

Connectivity / Bluetooth® (5.0), USB Type-CTM, and 3.5mm

sensors: AV jack

Battery: 1450mAh² battery.

Audio: MP3 Player³, FM radio (Wired/Wireless)

Dimensions: 108.4*55.1*18.9 123.5g

Camera VGA camera with torch as flash

SIM card type: 4FF + 4FF

Battery times: Talk time up to 9 hours (in the lab

environment)

BARBIE™ and associated trademarks and trade dress are owned by, and used under license from, Mattel. ©2024 Mattel.

TM and © 2024 HMD Global. All rights reserved. Variations on offering may apply. Check local availability. All specifications, features and other product information provided are subject to change without notice. All images are for illustrative purposes only. Contains small parts. ¹Preinstalled system software and apps use a significant part of memory space. ²Battery has limited recharge cycles and battery capacity reduces over time. Eventually the battery may need to be replaced. ³MicroSD card required, sold separately.