

ENGLISH

User Guide	3
Frequently Asked Questions (FAQ)	3
Technical Specifications	3
AUDIO	3
ACTIVE NOISE CANCELLING (ANC)	3
TRANSPARENCY MODE	3
CONNECTIVITY	3
HANDS-FREE MICROPHONE	3
EARPHONE BATTERY	3
CHARGING CASE BATTERY	3
DISPLAY	4
INTERNAL MEMORY PLAYER	4
Safety and Maintenance	4
Hearing Loss Prevention	4
Warranty	4

ENERGY  SISTEM



Thank you for trusting us and purchasing your new Energy Chill Earphones. We hope you enjoy them.

User Guide

View the quick start guide by clicking [here](#).

Frequently Asked Questions (FAQ)

- **Can I create folders on my Energy Screensound's internal memory?**

No, the device is optimized to play files placed directly in the root of the device's memory.

- **What types of files can the Energy Screensound play?**

The device can play MP3 files directly from the root of the internal memory.

- **How do I reset the earbuds?**

Disconnect the earbuds from any Bluetooth sound source, place them in your ears, and press the touch control on both earbuds simultaneously 10 times quickly. You'll hear a "beep" sound, and they'll automatically turn off. Insert them into the charging case and take them out again to reconnect via Bluetooth.

- **How do I reset the case?** Keep pressed the button of the case during 5 seconds or more. Device will restart automatically

Technical Specifications

AUDIO

- Frequency response: 20 Hz ~ 20 kHz
- Driver diameter: 10 mm
- Design: In-ear
- Type: Dynamic

ACTIVE NOISE CANCELLING (ANC)

- -25 dB of Noise reduction between 20 and 1000 Hz

TRANSPARENCY MODE

- Transparency mode for amplifying external sound when you need

CONNECTIVITY

- Bluetooth version 5.4, class II
- Operating frequency: 2.4 GHz
- Maximum signal strength: < 20.00 dBm
- Supported Bluetooth profiles: HSP / HFP / A2DP / AVRCP
- Supported Bluetooth codecs: SBC / AAC
- Up to 20 meters range
- Hands-free function
- Compatible with Google/Siri voice assistant

HANDS-FREE MICROPHONE

- Type: Built-in
- Sensitivity: -38 dB ± 3 dB (@ 1 kHz)
- Frequency range: 100 Hz ~ 10 kHz

EARPHONE BATTERY

- Capacity: 40 mAh / 3.7 V
- Type: Lithium Polymer
- Battery life at medium volume: 5 hours*
- Battery life at medium volume with ANC ON: 4 hours*
- Charging time: 1 hour

CHARGING CASE BATTERY

- Capacity: 300 mAh / 3.7 V
- Type: Lithium Polymer

- Extra battery life: 20 hours*
- Extra battery life with ANC ON: 16 hours*
- Charging time: 2 hours
- Charging system: USB Type-C

DISPLAY

- TFT Color technology
- Size: 2,01"

INTERNAL MEMORY PLAYER

- Capacity: 1GB
- Folders navigation: NO
- Compatible Audio Formats: MP3

*This information is approximate. Battery life depends on the volume selected and the type of music played.

Safety and Maintenance

- Do not expose the device to impact, dust, moisture, or high temperatures.
- Do not apply corrosive or abrasive cleaning products to the device.
- Do not disassemble the device. Any repairs should be performed only by qualified personnel from Energy Sistem Technology, S.A.
- Make sure to keep the device off when not in use and do not leave it for long periods of time with the battery fully discharged.
- Keep the device and its packaging out of the reach of children and pets to avoid possible accidents.
- Do not use the device while driving a vehicle.

Hearing Loss Prevention

Listening to music at high volume for long periods of time can cause permanent hearing damage. To prevent hearing damage, we recommend lowering the volume on your music player before starting music playback and then gradually increasing the volume until you reach a comfortable, moderate listening level.

Warranty

You can check the warranty conditions [here](#).